

G. Jones
17/02/2022
V2
070001

PREPARED
DATE
VER NO.
PRODUCT CODE



Instruction Manual

FOR

Soundwall



WARNING:
CHOKING HAZARD – Small Parts
Not suitable for children under 3 years.
This is not a toy

For optimal results, please read and follow
instructions carefully
Please keep for future reference

experia
multisensory for everyone

Experia
Acorn Phase 3, High Street
Barnsley, South Yorkshire
S72 7BD, United Kingdom

T 0800 612 6077
E info@experia.co.uk
W www.experia.co.uk

Instruction Manual

Congratulations on the purchase of your Soundwall!

The Soundwall has been designed specifically for people with special needs and should, if used in accordance with these guidelines, offer years of learning and fun!

The Soundwall offers endless opportunities to develop cause and effect, speech and language skills and many more.

Please ensure you read this Instruction Manual in full before operating the unit.

Heed all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. This product is intended to be installed and/or use by a trained professional. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

Features

- 18 hours of recording time
- 8 groups of pre-recorded sounds
- 2 groups of user recorded sounds
- 80 sounds available in total
- Easy to use
- 2 Year Manufacturers Guarantee (Collect and Return)

Pack contents

1 x Soundwall
1 x Power Supply

Instruction Manual

Sound Groups

- 0 - User recorded sounds
- 1 - User recorded sounds
- 2 - Domestic Animals
- 3 - Household Sounds
- 4 - Numbers One to Eight
- 5 - Favorite Colour - English
- 6 - Favorite Colour - Spanish
- 7 - Transport
- 8 - Circus
- 9 - Nursery Rhymes

Controls



Volume – controls the playback volume

Pair Button – No Function on this product

Sound No – Sound Group number

Sound Select – press to select Sound Groups

Microphone – for recording into

Record Button – press to enter Record Mode

Instruction Manual

Getting Started

1. Switch on the unit via the mains after plugging in the power supply.
2. Choose the group of sounds you'd like to hear by pressing the Sound Select button.
3. Now it's ready to use, activate one of the buttons and the speaker responds.

Recording your own Sounds

After switching the unit on please follow the instructions below to record a message onto the Soundwall. Messages can be recorded over again and again. This is only relevant to Sound Groups 0 and 1.

1. Decide which coloured hand (switch) you want to record your message / sound to.
2. Select Sound Group 0 or 1 and Press the "Record" button – the display flashes "r" to indicate Recording Mode for a few minutes until you continue the next step.
3. Touch the chosen coloured hand once.
4. The unit will now begin recording – make the sound you want to record. Once the sound has been recorded touch the coloured hand once again to stop the recording. This may take a little practice to get right.
5. Touch the coloured hand to check the sound recording.
6. Continue to record onto the other window positions by repeating the above.

Please note a single bar is displayed if no sound is available for playback.

Cleaning and Maintenance

The unit should be cleaned with a damp soft cloth. A non abrasive cleaning agent may be used for stubborn stains. Ensure no liquid enters the unit.

The unit has been designed for use by people with special needs however this does NOT mean it is unbreakable. You must ensure the unit is not dropped, thrown, stood upon, immersed in water, etc.

Instruction Manual

Troubleshooting

Q. The unit doesn't work.

A1. Is it switched on? If so,

A2. Have you checked the volume control, if so

A3. Have you checked though all the sound groups, if so

Please contact us.

Contact Details

For USA please email office@experia-usa.com

For UK and rest of the world email operations@experia.co.uk

Telephone: 0044 (0) 845 644 0977.

Please note: email is our support teams preferred communication and this takes precedence over telephone calls.

QUESTIONS & IDEAS?

If you have an idea on how to improve this product or want to see your product idea realised, please email: operations@experia.co.uk

All ideas are presented to our OT, technical and finance department and if all procedures are passed we will contact you to discuss your idea further.

We can't promise to develop every product but if it's a great idea, we'll try!

Manufactured proudly in the UK by:

Experia, Acorn Phase 3, High Street, Grimethorpe, S72 7BD, UK.



© Copyright 2022 Experia All rights reserved. Experia is a registered trademark